



Note:-

- 1) Wiring to be in accordance with current IEE regulations
- 2) Refer also to the fitting and wiring instructions for the fans and controllers

Control description:-

Sentinel Kinetic switching from trickle to Boost by two light switch, or cooker hood switch, or Ambient Response.

A	XXXX	7.4.2009	STAU
ISSUE	MOD	DATE	CHK'D

<p>ORIGINAL DRAWING SIZE A3</p> <p>ALL DIMENSIONS IN MILLIMETRES TOLERANCES UNLESS OTHERWISE SPECIFIED:- ±0.5 ON NOMINAL DIMENSIONS ±0.2 ON 1 DECIMAL PLACE DIMENSIONS ±0.1 ON 2 DECIMAL PLACE DIMENSIONS ±0.1 ON HOLE DIAMETERS ETC ±1.0 DEGREE ON ANGULAR DIMENSIONS</p>	<p>This drawing/document is COPYRIGHT and the property of VENT-AXIA Ltd. It must not be copied (in whole or in part), used for manufacture or otherwise disclosed without prior written consent of the company. Any copies of this drawing/document made by any method must also include a copy of this legend. © VENT-AXIA Ltd. 2002</p>	<p>DRAWN DGBSON DATE 7.4.2009 CHK'D DATE</p>	<p>TITLE</p> <p>Wiring Diagram Sentinel Kinetic two L.S., Humidistat Remote C.H.</p>		
		<p>MATERIAL -</p>	<p>PART No</p> <p>DRG 441879 A</p>		
		<p>FINISH -</p>	<p>SCALE -</p>	<p>PROJECTION </p>	
		<p>PRODUCT</p>	<p></p>		