



N.B.
PURGE VIA CONTROL ON
FAN UNIT OR OPTIONAL
WIRELESS CONTROLLER

Note:-

- 1) Wiring to be in accordance with current IEE regulations
- 2) Refer also to the fitting and wiring instructions for the fans and controllers

Control description:-

Sentinel Kinetic switching from trickle to Boost by a light switch, or cooker hood switch, or Ambient Response.

A	XXXX	7.4.2009	STAU
ISSUE	MOD	DATE	CHK'D

ORIGINAL DRAWING SIZE A3	ALL DIMENSIONS IN MILLIMETRES TOLERANCES UNLESS OTHERWISE SPECIFIED:- ±0.5 ON NOMINAL DIMENSIONS ±0.2 ON 1 DECIMAL PLACE DIMENSIONS ±0.1 ON 2 DECIMAL PLACE DIMENSIONS ±0.1 ON HOLE DIAMETERS ETC ±1.0 DEGREE ON ANGULAR DIMENSIONS	This drawing/document is COPYRIGHT and the property of VENT-AXIA Ltd. It must not be copied (in whole or in part), used for manufacture or otherwise disclosed without prior written consent of the company. Any copies of this drawing/document made by any method must also include a copy of this legend. © VENT-AXIA Ltd. 2002	DRAWN DGIbson	DATE 7.4.2009	CHK'D	DATE	TITLE Wiring Diagram Sentinel Kinetic two L.S. Humidistat, Built in C.H.
							PART No
							DRG
							441883
					PROJECTION		A