


# WIRING DIAGRAM - 1


For use with:  
 VA140KP  
 VA140UP  
 VA140KH  
 VA140UH  
 VA140VS  
 CENTRIF 170DP  
 CENTRIF 250DP  
 CENTRIF 170HP  
 CENTRIF 250HP  
 VA150P  
 VA150A  
 VA150X  
 VA150H  
 VA100X/VA100WCX  
 (VA100LH/VA100XH)  
 SOLO P  
 SOLO DP  
 SOLO TM 2  
 SOLO HP2  
 SOLO PLUS P  
 SOLO PLUS TM  
 LOWATT U/KP  
 LOWATT U/KH

USING THE INTEGRAL PULLCORD SWITCH (WHERE APPLICABLE)



# WIRING DIAGRAM - 2

For use with:  
 CENTRIF 170  
 CENTRIF 250  
 SILHOUETTE 100  
 SILHOUETTE 150X  
 VA100L  
 VA140VS



# WIRING DIAGRAM - 3

For use with:  
 VA140KT  
 VA140UT  
 VA140KH  
 VA140KHT  
 CENTRIF 250DP  
 CENTRIF 170HP  
 CENTRIF 250HP  
 CENTRIF 170T  
 CENTRIF 250T  
 VA150T  
 VA150HT  
 VA150H  
 SILHOUETTE 100T  
 SILHOUETTE 100H  
 SILHOUETTE 100TM  
 SILHOUETTE 150XT  
 SILHOUETTE 150XH  
 VA100XT/VA100LT  
 VA100WCXT/VA100XHT  
 (VA100LH/VA100XH)  
 SOLO DP  
 SOLO T  
 SOLO HP2  
 SOLO HT  
 SOLO PLUS T  
 SOLO PLUS HT  
 LOWATT U/KT

